

KIT LISTING

Valve No.	Seal Repair Kit	XX-XXX-03 1-1/4" Ext. Stem Kit	XX-XXX-04 2-1/4" Ext. Stem Kit	XX-XXX-50 2-1/4" Locking Ext. Kit	XX-1XX-62 Body Center Section	XX-XXX-16 XX-XXX-58 Chain Lever Kit	-19 -27 Lock Device		XX-XXX-93 1-1/4" Ext. Stem & Bal. Stop Kit	XX-XXX-94 2-1/4" Ext. Stem & Bal. Stop Kit	XX-X2X-XX Adjustable Stop Lever Kit
82-101	82-002-01	78-439-01	78-442-01	78-001-01	82-102-62		78-510-01		78-462-01	78-466-01	78-565-01
82-102 82-202	82-002-01	78-439-01	78-442-01	78-001-01	82-102-62		78-510-01		78-462-01	78-466-01	78-565-01
82-103 82-203	82-003-01	78-440-01	78-443-01	78-002-01	82-103-62	78-407-01	78-511-01 W-6483-00		78-463-01	78-467-01	78-566-01
82-104 82-204	82-004-01	78-440-01	78-443-01	78-002-01	82-104-62	78-407-01	78-512-01 W-6483-00		78-463-01	78-467-01	78-566-01
82-105 82-205	82-005-01	78-441-01 see note 1	78-444-01 see note 2	78-003-01	82-105-62	78-408-01	78-513-01 W-6484-00		78-464-01	78-468-01	78-567-01
82-106 82-206	82-006-01	78-441-01 see note 1	78-444-01 see note 2	78-003-01	82-106-62	78-408-01	78-514-01 W-6484-00		78-464-01	78-468-01	78-567-01
82-107 82-207	82-007-01	78-445-01 see note 3	78-446-01 see note 4	78-005-01	82-107-62	78-408-01	78-515-01 W-6836-00		78-586-01	78-587-01	78-567-01
82-108 82-208	82-008-01	78-445-01 see note 3	78-446-01 see note 4	78-005-01	82-108-62	78-408-01	78-516-01 W-6836-00		78-586-01	78-587-01	78-567-01
82-109 82-209	82-009-01				82-109-62		W-8075-00				
82-140 82-240	82-000-01		4" ext. 78-1409-01		82-140-62		78-862-01				
82-14A 82-24A	82-00A-01		4" ext. 78-1410-01		82-14A-62		78-863-01				

Note 1. With wheel handle, use kit # 78-517-01.

Note 2. With wheel handle, use kit # 78-518-01.

Note 3. With wheel handle, use kit # 78-931-01.

Note 4. With wheel handle, use kit # 78-932-01.

82-100 Series, NPT / 82-200 Series, Solder

Apollo, Bronze, 3-piece, Full Port